

# SPARE PARTS LIST

PAGE 1

MODEL NO. AC310H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	HY00000213	HEX. SOCKET HEAD BOLT M6x90	4	
002	HY00000214	Spring Washer 6	4	
003	HY00000215	FLAT WASHER 6	4	
004	HY00000216	CYLINDER HEAD	1	
005	HY00000217	HEAD GASKET	1	
006	HY00000218	Valve Plate	1	
007	HY00000219	Outlet Valve	1	
008	HY00000220	INLET VALVE	1	
009	HY00000221	CYLINDER GASKET L	1	
010	HY00000223	CYLINDER L 50H	1	
011	HY00000224	ELBOW 8R1/4	1	
012	HY00000225	RING 8	1	
013	HY00000226	RING NUT	1	
014	HY00000227	ELBOW 10-R3/8	1	
015	HY00000228	Ring 10	1	
016	HY00000229	RING NUT	1	
017	HY00000230	CONNECTING ROD	1	
018	HY00000231	SHEET RING	1	
019	HY00000232	LEAF SPRING	1	
020	HY00000233	Wearing L	1	
021	HY00000234	HEX NUT M18	1	
022	HY00000235	CONED DISC SPRING 18	1	
023	HY00000237	BALANCER 50H	1	
024	HY00000238	Spacer	1	
025	HY00000239	Crank Spacer L	1	
026	HY00000240	Crank Spacer H	1	
027	HY00000241	PAN HEAD SCREW M5X16	3	
028	HY00000242	FLAT WASHER	3	
029	HY00000243	TAPPING SCREW 4X18	3	
030	HY00000244	Filter Cover	1	
031	HY00000245	Filter	1	
032	HY00000246	Crank Case Cover	1	
033	HY00000247	O RING	1	
034	HY00000248	CONNECTING ROD	1	
035	HY00000249	Sheet Ring H	1	
036	HY00000250	LEAF SPRING	1	
037	HY00000251	Wearing H	1	
038	HY00000252	PIPE 8	1	
039	HY00000253	HEX. SOCKET HEAD BOLT M8X70	4	
040	HY00000254	FLAT WASHER 8	4	
041	HY00000255	Spring Washer 8	4	
042	HY00000256	Cylinder Head H	1	
043	HY00000257	HEAD GASKET	1	
044	HY00000258	VAVLE PLATE H COMPLETE	1	
045	HY00000259	CYLINDER GASKET H	1	
046	HY00000261	CYLINDER H 50H	1	
047	HY00000262	Staffing L	1	
048	HY00000263	Staffing H	1	
049	HY00000264	HEX. NUT M8	1	
050	HY00000266	CAPACITOR RUN ASSY	1	
051	HY00000267	HEX. SOCKET BOLT M6X40	4	
052	HY00000268	FLAT WASHER 6	4	
053	HY00000269	SLEEVE 6	4	
054	HY00000270	CUSHION	4	
055	HY00000271	Crank Case Ass'y	1	
056	HY00000272	BALL BEARING	1	
057	HY00000273	BEARING RETAINER	1	
058	HY00000274	COUNTERSUNK HEAD SCREW M5X20	3	

# SPARE PARTS LIST

PAGE 2

MODEL NO. AC310H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
059	HY00000276	Stator	1	
060	HY00000277	KEY 6	1	
061	HY00000278	ROTOR	1	
062	HY00000279	BALL BEARING 6303LLB	1	
063	HY00000280	O-RING 49	1	
064	HY00000281	REAR BRACKET	1	
065	HY00000242	FLAT WASHER	4	
066	HY00000282	Spring Washer 5	4	
067	HY00000283	HEX. BOLT M5X146	4	
068	HY00000284	FAN 195	1	
069	HY00000285	RETAINING RING 14	1	
070	HY00000286	MOTOR COVER B	1	
071	HY00000287	BUSHING	1	
072	HY00000289	THERMAL CIRCUIT BREAKER	1	
073	HY00000290	MOTOR COVER C	1	
074	HY00000292	POWER SUPPLY CORD	1	
075	HY00000295	Cord Cramp	1	
076	HY00000297	Cord Cramp	2	
077	HY00000299	SWITCH	1	
078	HY00000300	RING NUT 6	1	
079	HY00000301	PIPE 6	1	
080	HY00000302	barrel Nipple R1/4-25	1	
081	HY00000303	CHECK VALVE	1	
082	HY00000304	RING 6	1	
083	HY00000305	RING NUT 6	1	
084	HY00000228	Ring 10	1	
085	HY00000229	RING NUT	1	
086	HY00000306	PIPE 10	1	
087	HY00000307	PLUG 1/2	2	
088	HY00000308	RUBBER SEAL	2	
089	HY00000310	TANK ASSY.	1	
090	HY00000311	INDICATION LABEL	1	
091	HY00000312	DRAIN SOCKET	1	
092	HY00000313	PAN HEAD SCREW M5X10	7	
093	HY00000282	Spring Washer 5	7	
094	HY00000242	FLAT WASHER	7	
095	HY00000314	Side Panel Cover	1	
096	HY00000315	Side Panel	1	
097	HY00000316	FRAME COMPLETE	1	
098	HY00000317	FOOT	4	
099	HY00000318	SLEEVE 6	4	
100	HY00000319	FLAT WASHER 6	4	
101	HY00000320	HEX. SOCKET BOLT M6X12	4	
102	HY00000215	FLAT WASHER 6	4	
103	HY00000321	Hex Nut M6	8	
104	HY00000214	Spring Washer 6	4	
105	HY00000322	Hex Nut M5	2	
106	HY00000323	PIPE 8	1	
107	HY00000325	FRONT PANEL	1	
108	HY00000241	PAN HEAD SCREW M5X16	3	
109	HY00000282	Spring Washer 5	3	
110	HY00000242	FLAT WASHER	3	
111	HY00000327	FRONT PANEL	1	
112	HY00000328	GAUGE COVER	3	
113	HY00000329	INDICATION LABEL	1	
114	HY00000331	SAFETY VALVE	1	
115	HY00000333	Manifold	1	
116	HY00000336	barrel Nipple R1/4-30	1	

# SPARE PARTS LIST


PAGE 3

MODEL NO. AC310H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
117	HY00000338	Quick Coupler	2	
118	HY00000340	Taper Screw Plug 1/4	1	
119	HY00000341	Regulator	1	
120	HY00000342	INDICATION LABEL	1	
121	HY00000343	Pressure Gauge Joint	1	
122	HY00000344	Pressure Gauge L	1	
123	HY00000346	Manifold	1	
124	HY00000347	Pressure Gauge H	1	
125	HY00000348	Regulator	1	
126	HY00000349	INDICATION LABEL	1	
127	HY00000350	Manifold	1	
128	HY00000351	Quick Coupler Screw left	2	
129	HY00000352	RUBBER SLEEVE	2	
130	HY00000354	Safety Valve	1	
131	HY00000355	INDICATION LABEL	1	
132	HY00000357	MOTOR COVER	1	
133	HY00000360	CAUTION LABEL	1	
134	HY00000243	TAPPING SCREW 4X18	4	
135	HY00000361	CHECK VALVE	1	
136	HY00000362	Unloading Valve	1	
137	HY00000363	O-RING 17	1	
139	HY00000282	Spring Washer 5	3	
140	HY00000238	Spacer	1	
141	HY00000214	Spring Washer 6	4	
142	HY00000224	ELBOW 8R1/4	1	
143	HY00000225	RING 8	1	
144	HY00000226	RING NUT	1	
145	HY00000238	Spacer	1	
146	HY00000243	TAPPING SCREW 4X18	5	
147	HY00000267	HEX. SOCKET BOLT M6X40	4	
148	HY00000224	ELBOW 8R1/4	1	
149	HY00000225	RING 8	1	
150	HY00000226	RING NUT	1	
151	HY00000225	RING 8	1	
152	HY00000226	RING NUT	1	
153	HY00000340	Taper Screw Plug 1/4	1	
154	HY00000336	barrel Nipple R1/4-30	1	
155	HY00000336	barrel Nipple R1/4-30	1	
156	HY00000340	Taper Screw Plug 1/4	1	
157	HY00000336	barrel Nipple R1/4-30	1	
158	HY00000340	Taper Screw Plug 1/4	1	
159	HY00000336	barrel Nipple R1/4-30	1	
160	HY00000343	Pressure Gauge Joint	1	
161	HY00000347	Pressure Gauge H	1	
162	HY00000336	barrel Nipple R1/4-30	1	
163	HY00000340	Taper Screw Plug 1/4	1	
164	HY00000313	PAN HEAD SCREW M5X10	4	
165	HY00000282	Spring Washer 5	4	
166	HY00000242	FLAT WASHER	4	
167	HY00000224	ELBOW 8R1/4	1	
168	HY00000219	Outlet Valve	1	
169	HY00000220	INLET VALVE	1	
171	HY00000365	Carton	1	
172	HY00000366	CASTER	1	

# SERVICE DRAWING

MODEL NO. AC310H



# SERVICE DRAWING

MODEL NO. AC310H

