

SPARE PARTS LIST

PAGE 1

MODEL NO. BDA341

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266069-6	Önmetszo csavar M4x45	4	
002	317634-5	GEAR HOUSING	1	
003	227538-2	SPIRAL BEVEL GEAR 9	1	
004	210029-0	Golyóscsapágó	1	
005	324930-4	LOCK RING	1	
006	331647-2	Lock cam	1	
007	227221-1	Spur Gear 29	1	
008	231956-8	Tekercsrugó 6 6940DW/6706L/670	1	
009	210033-9	Golyóscsapágó	1	
010	450607-6	Gear Housing Cover	1	
012	194427-5	Szénkefe /BDF452RFE	1	
013	268100-4	PIN 3.5	2	
014	539189-2	BRUSH HOLDER ASSY BDA340/341 INC. 12	1	
015	619232-4	Armature	1	
016	638613-3	YOKE UNIT	1	
017	188534-4	Housing set INC. 35	1	
018	266130-9	Önmetszo csavar M3x16*	5	
019	210029-0	Golyóscsapágó	1	
020	961052-5	Seeger-gyuru S-12 961052-5	1	
021	227537-4	SPIRAL BEVEL GEAR 26	1	
022	211131-2	Golyóscsapágó 6001DDW 211131-2	1	
023	317633-7	BEARING BOX	1	
024	324329-3	SPINDLE	1	
025	285842-5	Csapágyfedél /DA3010F	1	
026	766005-7	KEYLESS DRILL CHUCK	1	
027	254201-4	Kulcs	1	
028	631814-2	Led Circuit	1	
029	689098-6	Hoelvezeto lap	1	
030	911006-2	Trapézfeju csavar M3x8 911006-	1	
031	650606-0	Switch C3HZ-1A-TPLM	1	
032	450610-7	F/R Change Lever	1	
033	450609-2	LINK	1	
034	450608-4	Switch lever	1	
035	188534-4	Housing set INC. 17	1	
036	865496-0	Name Plate BDA341	1	
037	643811-6	Akku csatlakozó	1	
038	418036-9	Gasket	1	
A01	153489-2	GRIP 36 COMPLETE	1	
A02	***DC18RA	DC18RA FAST CHARGER	1	
A03	194065-3	BATTERY BL1430 SET	2	
A04	450128-8	BATTERY COVER	1	
A05	824851-5	Plastic carrying case	1	

SERVICE DRAWING

MODEL NO. BDA341

