

SPARE PARTS LIST

PAGE 1

MODEL NO. BGA452

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	619218-8	Forgórész/ BGA452	1	
002	317821-6	Fogaskerékház fedél	1	
003	213445-5	O gyuru	1	
004	961005-4	Seeger-gyuru S-9 961005-4*	1	
005	210042-8	#Golyóscsapágy 629LLB	1	
006	227501-5	Kúpkerék BGA	1	
007	417771-6	Sapka MT952	1	
008	233072-2	Nyomórugó 8 9541/9542/9227C*	1	
009	266361-0	Csavar	4	
010	213960-9	#O-gyuru 5	1	
011	256496-5	Csapszeg BGA452	1	
012	318051-2	Fogaskerékház BGA452	1	
013	263002-9	Gumi csapszeg 4 263002-9	1	
014	210033-9	Golyóscsapágy	1	
015	961052-5	Seeger-gyuru S-12 961052-5	1	
016	253744-3	Lapos Alátét 12	1	
017	227502-3	Tányérkerék BGA	1	
018	962151-6	Seeger-gyuru R-32 962151-6*	1	
019	211129-9	Golyóscsapágy 6201DDW 211129-9	1	
020	267238-2	Alátét 12	1	
021	213622-9	O gyuru	1	
022	318331-6	BEARING BOX	1	
023	911121-2	Trapézfeju csavar M4x14 911121	4	
024	345464-4	Gyuru	1	
025	254011-9	Ék 4 254011-9	1	
026	324489-1	Tengely	1	
027	265180-1	PAN HEAD SCREW M5x16	1	
028	122886-3	WHEEL COVER ASS'Y INC. 27	1	
029	224415-9	Belso illesztoperem	1	
030	224554-5	Biztosítóanya 14-45, 45 mm (új)	1	
031	631714-6	Led áramkör BGA	1	
032	638376-1	Mágnesgyuru	1	
033	638448-2	Szénkefetartó BGA	1	
034	862598-3	NAME PLATE BGA452S new	1	
035	266326-2	Csavar 4X18	5	
036	419566-3	Kapcsológomb	1	
037	188761-3	HOUSING SET INC. 42	1	
038	419519-2	Kapcsolókar BGA	1	
039	650579-7	Kapcsoló BTB	1	
040	631713-8	Elektronika/BGA452	1	
041	643838-6	Terminal BTB/BDF/BHP/BGA/BJR	1	
042	188761-3	HOUSING SET INC. 37	1	
043	191971-3	Szénkefe CB-430 (CB-420), új	1	
044	643954-4	Tartó	2	
045	419518-4	HOLDER CAP COVER	2	
A01	153489-2	GRIP 36 COMPLETE	1	
A02	782423-1	LOCK NUT WRENCH 35	1	
A03	***DC18SC	DC18SC CHARGER	1	
A04	194204-5	BATTERY BL1830 SET	2	
A05	824767-4	PLASTIC CARRYING CASE	1	
A08	450128-8	BATTERY COVER	1	
E02	805459-4	Safety instruction label	1	

SERVICE DRAWING

MODEL NO. BGA452

