

# SPARE PARTS LIST

PAGE 1

MODEL NO. DC18SC

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	803613-4	Charging Condition Label	1	
002	418278-5	ACRYLIC PIN	1	
003	418181-0	Terminal Cover	1	
004	231474-6	COMPRESSION SPRING 4	2	
005	188053-0	CHARGER CASE SET	1	
		INC. 1,2,18		
006	266278-7	TAPPING SCREW FLANGE BT3x10	1	
007	638357-5	TERMINAL UNIT	1	
008	638499-5	Ventillátor	1	
009	233194-8	Nyomórugó 4 233194-8	1	
010	419357-2	CHARGER CASE COVER NEW	1	
011	667985-9	Vinil kábel 0,75-2-2,0 DC1410/	1	
012	647306-1	Varisztor - félvezeto	1	
014	652781-8	FUSE	1	
015	631697-0	Charging circuit	1	
		INC. 12,14		
016	266346-6	TAPPING SCREW BT 4x20	4	
017	286255-3	Sapka 13	4	
018	819226-1	MAKITA Logo Label	1	

