

SPARE PARTS LIST

PAGE 1

MODEL NO. HT355

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	450493-5	Switch Lever B	1	
002	233157-4	Compression Spring	1	
003	450442-2	Front Grip	1	
004	158629-7	Protector cpl.	1	
005	265995-6	Önmetszo csavar M4x18*	2	
006	911253-5	Trapézfeju csavar M5x30 911253	2	
008	188568-7	Housing Set INC. 42	1	
009	417740-7	Insulation Cap	1	
010	233288-9	Nyomórugó*	1	
011	268077-3	Pin 5	1	
012	417727-9	Cap Holder	1	
013	417736-8	Lifter	1	
014	417735-0	Pusher Cap	1	
015	268237-7	Rod 3	1	
016	417781-3	Pin Holder	1	
017	646206-2	Choke Coil	1	
018	646207-0	Choke Coil	1	
019	417737-6	Link	1	
020	417739-2	Rod	1	
021	233156-6	Compression Spring 5	1	
022	417731-8	Switch Lever C	1	
023	265995-6	Önmetszo csavar M4x18*	2	
024	687063-9	Kábel-feszültségmentesítő 6870	1	
025	450443-0	Switch Lever A	1	
026	233156-6	Compression Spring 5	1	
027	450488-8	Lever	1	
028	643936-6	Szénkefetartó 8450/HP2040/6408	2	
029	191962-4	Szénkefe CB-419 (CB-406, CB-40	1	
030	621733-0	Állórész UH6570	1	
031	211027-7	Ball Bearing 627ZZ	1	
032	515738-9	Forgórész UH6570 INC. 31,33,34	1	
033	241850-6	Ventilátorkerék 60 HP2032/HP20	1	
034	211062-5	Golyóscsapágy 6000ZZ	1	
035	650628-0	Kapcsoló UH	1	
036	645190-8	NOISE SUPPRESSOR	1	
037	654531-7	Csatlakozósáv N910/4305/4305T	1	
038	666246-4	Power Supply Cord 1.5-2-0.3	1	
039	682503-2	#Kábelvédo 8-90*	1	
040	253215-0	Lapos Alátét 8 253215-0	1	
041	253215-0	Lapos Alátét 8 253215-0	1	
042	188568-7	Housing Set INC. 8	1	
043	865775-6	Name Plate HT-355	1	
044	265995-6	Önmetszo csavar M4x18*	10	
045	158625-5	Gear Housing Complete	1	
046	158623-9	Gear Complete	1	
047	443142-1	Dust Guard	1	
048	194664-1	Shear Blade Ass'y Set	1	
049	158626-3	Gear Housing Cover cpl.	1	
050	265182-7	+Pan HEad Screw M5x25	2	
051	450440-6	Under Cover	1	
052	911148-2	Trapézfeju csavar M4x25 911148	4	
A01	194678-0	Cord Holder Complete	1	
A02	158024-1	* Kábeltartó horog sövénynyíró o	1	
A03	450491-9	BLADE COVER HT-345	1	

SERVICE DRAWING

MODEL NO. HT355

