

SPARE PARTS LIST

PAGE 1

MODEL NO. MS20U

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	6274501000	Grip	1	
002	6274500901	Handle	1	
003	6254031001	Handle Holder Ass'y INC.4,5	1	
004	0119059890	Imbuszcsavar M5x25 RBC250/22	4	
005	0119059940	Hex. Socket Head Bolt M5x25	2	
006	6197005001	Hanger Ass'y INC.7	1	
007	0140059360	SCREW & WASHER ASS'Y	1	
008	6254502100	GRIP	1	
009	6259514700	CAUTION LABEL	1	
010	6191001001	SHAFT PIPE COMPLETE	1	
011	6199526100	CAUTION LABEL	1	
012	6274501200	Handle	1	
013	6195020000	CONTROL LEVER ASS'Y	1	
014	6198014000	PROTECTOR ASS'Y INC.15,18-20	1	
015	6258061001	Védoburkolat EM4250 INC.16,17	1	
016	0100069790	Bolt M6x30	2	
017	6258508200	PROTECTOR CLAMP	1	
018	0140059380	Screw Assembly	2	
019	6198008001	PROTECTOR COMPLETE	1	
020	0021805000	NUT	2	
021	0119059490	SOCKET HEAD BOLT M5x14 new	1	
022	6243006002	Szöghajtás DBC260 INC.23-36	1	
023	6253011012	Csavar RBC250	1	
024	6218500200	Támasztó alátét RBC	1	
025	0140059390	Screw Assembly	2	
026	0600069990	Golyóscsapágy a hajtásnál, új	1	
027	0600109910	Golyóscsapágy 600DDU RBC225/2	1	
028	0031426000	Biztosítógyuru, belso RBC225	1	
029	6218501601	Felfogóalátét RBC225/255	1	
030	6218003001	Felfogóalátét, komplett RBC	1	
031	6258505001	Balmenetes kést felfogató anya	1	
032	6243008002	Kúpkérékpár DBC260U	1	
033	0119059890	Imbuszcsavar M5x25 RBC250/22	1	
034	6212500300	Golyóscsapágy 609ZZ RBC225/255	1	
035	6193006120	Outer Snap Ring	1	
036	0031424000	#Biztosítógyuru, belso RBC225	1	
037	6191500401	Meghajtótengely RBC/EM	1	
038	6195020000	CONTROL LEVER ASS'Y INC.39-47	1	
039	0119059980	SOCKET HEAD BOLT M5x30	1	
040	6195006060	TAPPING SCREW M4x20	2	
041	6195020010	Wire Set INC.42	1	
042	6195020020	CONTROL CABLE	1	
043	6215022030	Lever	1	
044	6195006050	SPRING	1	
045	6215023060	Lever	1	
046	6195006150	Top	1	
047	6215022040	NUT M5	1	
048	5103502801	SPACER GASKET	1	
049	0140059500	Csavar M5x25 RBL250/RST225/	2	
050	5233014000	INSULATOR COMPLETE	1	
051	6165500201	Wire 1	1	

SPARE PARTS LIST

PAGE 2

MODEL NO. MS20U

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
052	5193500501	INSULATOR GASKET	1	
053	0119059730	Imbuszcsavar M5x20 RST/RBC/RBL	2	
054	5197500100	PLUG CAP COVER	1	
055	0650149661	Gyújtógyertya DBC260	1	
056	5191500702	CYLINDER	1	
057	5195503100	CYLINDER COVER	1	
058	6169508100	TRADE MARK LABEL	1	
059	0150059790	TAPPING SCREW M5X14	1	
060	0655009870	Plug Cap	1	
061	0654009931	Rugó a gyertyacsatlakozó sapká	1	
062	0851089950	Tube	1	
063	5197018000	WIRE COMPL	1	
064	0140049770	Csavar M4x16	2	
065	5197011010	IGNITION COIL	1	
066	0119059520	SOCKET HEAD BOLT M5x40	2	
067	5193001002	EXHAUST MUFFLER INC.68	1	
068	5193001050	Spark Arrester	1	
069	5193500002	MUFFLER INSULATOR	1	
070	5191500301	CYLINDER GASKET	1	
071	5192500600	PISTON RING	1	
072	5192500800	PISTON	1	
073	5192500500	Piston Pin	1	
074	0565089970	Szorítókapocs RST250/RBC250/22	2	
075	5192001003	CRANKCASE ASS'Y	1	
076	5195009000	Rewind Starter INC.77-84	1	
077	5195500000	PULLEY	1	
078	5195002060	SET SCREW	1	
079	5195002100	SWING ARM	1	
080	5195002110	COLLAR	1	
081	5195002030	REEL	1	
082	5195002050	SPIRAL SPRING	1	
083	5255016020	STARTER ROPE	1	
084	5225004020	Handle	1	
085	0140049770	Csavar M4x16	3	
086	6199526200	MODEL LABEL	1	
087	5191004001	Crank Case Ass'y INC.88-91	1	
088	0440109980	OIL SEAL	2	
089	5191500400	CRANKCASE GASKET	1	
090	0600109980	BALL BEARING 6000	2	
091	0140059520	Csavar M5x25 RST250/RBC250/	3	
092	5197017010	FLYWHEEL	1	
093	6192002003	CLUTCH ASSY.	1	
094	6192001001	CLUTCH DRUM	1	
095	6191006001	CLUTCH CASE	1	
096	0031510000	Biztosítógyuru 10, külso RST25	1	
097	0119059880	HEX.SOCKET HEAD BOLT M5X25	1	
098	6191500203	PIPE DAMPER	1	
099	6191501300	PIPE BRACKET	1	
100	0566059980	CLAMP	1	
101	0150059780	TAPPING SCREW M5X20	3	
102	0119059850	HEX. SOCKET HEAD BOLT M5x14	1	
103	5256059000	FUEL TANK CAP COMPL. INC.104,105	1	
104	5256058000	Tanksapka RST250	1	
105	5256067000	Heveder RBC/RBL/RBK/RST, új	1	

SPARE PARTS LIST


PAGE 3

MODEL NO. MS20U

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
106	5196500003	FUEL TANK CPL.	1	
107	0851159850	TUBE	1	
108	0561059990	Tömloszorító bilincs RBC220/22	1	
109	5236503900	Szuro RST250/RBC250/220/RBL	1	
110	5036500200	Lap RST250/RBC250/220/225/	1	
111	5036500300	Lap RST250/RBC250/220/225	1	
112	5193500101	PLATE	1	
113	5216500200	Lökésgátló RST250/RBC250/220/2	2	
114	5196036000	CARBURETOR INC.115-142	1	
115	5196019240	ADJUST SCREW	1	
116	5196019310	SCREW	2	
117	5196019450	LEVER END	1	
118	5196019460	WASHER	1	
119	5196036010	STARTER LEVER	1	
120	5196036020	STARTER SPRING	1	
121	5196019250	SLOW STOP SCREW	1	
122	5196019510	E-RING	1	
123	5196019220	O-RING	1	
124	5196019150	O-RING	1	
125	5196032010	MAIN JET	1	
126	5196019410	O-RING	1	
127	5196019360	CHECK VALVE ASSY	1	
128	5196019420	GUIDE PLATE	1	
129	5196019430	SCREW	1	
130	5196019040	DIAPHRAGM ASSY	1	
131	5196019050	DIAPHRAGM COVER	1	
132	5196019060	SCREW	2	
133	5196019110	PUMP PACKING	1	
134	5196019120	PUMP DIAPHRAGM	1	
135	5196019350	PUMP PLATE	1	
136	5196019130	PUMP PACKING	1	
137	5196019340	PUMP COVER	1	
138	5196019330	FILTER	1	
139	5246009030	COMBINATION VALVE	1	
140	5246009040	PRIMING PUMP	1	
141	5196019320	PRIMING PUMP PLATE	1	
142	5196019140	SCREW	4	
143	5193017040	O-Ring	1	
144	5193018010	Air Cleaner Plate Ass'y	1	
145	0043105600	Trapézfeju csavar M5x60 RST250	2	
146	5193017030	AIR CLEANER ELEMENT	1	
147	5193018020	AIR CLEANER CASE	1	
148	0140059480	SCREW ASS'Y M5x14	1	


SERVICE DRAWING

MODEL NO. MS20U




SERVICE DRAWING

MODEL NO. MS20U



SERVICE DRAWING

MODEL NO. MS20U



SERVICE DRAWING

MODEL NO. MS20U

