

SPARE PARTS LIST

PAGE 1

MODEL NO. PB500R

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	6621500201	VOLUTE CASE 1	1	
002	6621004003	VOLUTE CASE 2 COMPLETE	1	
003	0150059870	TAPPING SCREW M5X25	10	
004	0043605250	PAN HEAD SCREW M5X25	2	
005	0021705000	Nut M5	2	
006	6621006001	ELBOW COMPLETE	1	
007	0062630850	O RING	1	
008	6621005000	BRACKET COMPLETE	2	
009	6621500900	SPACER	2	
010	0150059910	TAPPING SCREW M5X10	4	
011	0023705000	Flange Nut M5	2	
012	6621500401	DAMPER	2	
013	0021706000	NUT M6	2	
014	0023706000	Peremes anya RST250	2	
015	6821500201	IMPELLER	1	
016	0011306250	BOLT & WASHER ASS'Y	3	
017	6622008001	FRAME COMPLETE	1	
018	6622500600	SIDE FRAME	2	
019	6622500701	KNOB	1	
020	0140059430	PAN HEAD SCREW M5X25	9	
021	0031205000	Alátét RBL250	11	
022	0023705000	Flange Nut M5	11	
023	6622010001	CUSHION COMPLETE	1	
024	6822500200	LOCK RIVET	4	
025	0140059430	PAN HEAD SCREW M5X25	2	
026	5256058000	Tanksapka RST250	1	
027	5256067000	Heveder RBC/RBL/RBK/RST, új	1	
028	6623003001	TUBE	1	
029	5236503900	Szuro RST250/RBC250/220/RBL	1	
030	6623005000	FUEL TANK ASS'Y	1	
		INC. 151		
031	8558502200	SPIRAL TUBE L=170	1	
032	8558501100	CLAMP M6XL=73	1	
033	6628010000	ENGINE COVER COMPLETE	1	
		INC. 34-39,40		
034	5105015110	SCREW	1	
035	5415003010	REEL	1	
036	5415003020	SPIRAL SPRING	1	
037	5415003030	WASHER	1	
038	5415001140	STARTER ROPE	1	
039	5305002110	STARTER KNOB	1	
040	5415011000	PULLEY UNIT	1	
		INC. 41-43		
041	5415011010	RATCHET	1	
042	5415011020	RETURN SPRING	1	
043	5215003040	E RING	1	
044	0200069920	WASHER M6	1	
045	0011306160	Csavar RST250/RBC225/255	1	
046	0043606200	Csavar M6x20 BHX2500	8	
047	5411012000	CRANK CASE ASS'Y	1	
		INC. 48-1,49-52		
048	0440179920	OIL SEAL	1	
049	0440159950	OIL SEAL	1	
050	0600179830	BALL BEARING 6203C3	1	
051	0600159880	BALL BEARING 6202C3	1	
052	5411501200	CRANKCASE GASKET	1	
053	5411501800	CYLINDER	1	
054	5411500501	CYLINDER GASKET	1	

SPARE PARTS LIST

PAGE 2

MODEL NO. PB500R

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
055	0119069990	HEX. SOCKET HEAD BOLT M6X18	4	
056	0119059940	Hex. Socket Head Bolt M5x25	4	
057	5412024000	CRANKSHAFT COMPLETE	1	
058	5412500700	PISTON	1	
059	5602501100	PISTON PIN	1	
060	5602500900	PISTON RING	2	
061	0610129950	NEEDLE ROLLER BEARING	1	
062	0565119990	CLIP	2	
063	0053203101	WOODRUFF KEY	1	
064	5413045003	MUFFLER	1	
065	5413046002	INSULATOR COMPLETE	1	
066	5413501700	MUFFLER GASKET	1	
067	5413502001	BOLT M6X13	2	
068	0200099990	WASHER M6	2	
069	0011506160	BOLT M6X16	1	
070	5413036000	LEAD VALVE ASS'Y	1	
071	5413502800	BRACKET GASKET	1	
072	5403500600	INSULATOR GASKET	1	
073	0119059630	SOCKET HEAD BOLT M5X20	4	
074	5417021010	FLYWHEEL	1	
075	5417024021	COIL	1	
076	0655009940	Gyertyacsatlakozó sapka RBL250	1	
077	0654009931	Rugó a gyertyacsatlakozó sapká	1	
078	0650149661	Gyújtógyertya DBC260	1	
079	0011308160	BOLT & WASHER ASS'Y	1	
080	0031108000	WASHER	1	
081	0119059790	HEX. SOCKET HEAD BOLT M5X22	2	
082	0011306250	BOLT & WASHER ASS'Y	4	
083	6628003000	WIRE COMPLETE	1	
084	5416043003	CARBURETOR	1	
		INC. 85-107,109-121		
085	5416043430	STRAINER	1	
086	5416043860	RETAINER	1	
087	5416043020	THROTTLE SHAFT ASS'Y	1	
088	5416043520	THROTTLE LEVER	1	
089	5416043030	THROTTLE RETURN SPRING	1	
090	5416043040	THROTTLE VALVE	1	
091	5416043260	DIAPHRAGM ASS'Y	1	
092	5416043110	PUMP DIAPHRAGM	1	
093	5416043310	METERING CHAMBER GASKET	1	
094	5416043120	PUMP GASKET	1	
095	5416043210	INLET NEEDLE VALVE	1	
096	5416043220	METERING LEVER SPRING	1	
097	5416043230	METERING LEVER	1	
098	5416043240	PIN	1	
099	5416043350	MAIN MIXTURE SCREW	1	
100	5416043360	IDLE MIXTURE SCREW	1	
101	5416043551	CHOKE SHAFT ASS'Y	1	
102	5416043620	CHOKE VALVE	1	
103	5416043540	POST	1	
104	5416043920	PRIMER BASE ASS'Y	1	
105	5416043510	SYRINGE	1	
106	5416043250	SCREW	1	
107	5416043050	SCREW	2	
109	5416043160	SCREW	1	
110	5416043530	SCREW	1	
111	5416043060	E RING	2	
112	5416043910	RETAINER SCREW	4	

SPARE PARTS LIST


PAGE 3

MODEL NO. PB500R

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
113	5416043850	COLLAR	1	
114	5416043760	TAPER RESIST LIMITER (R)	1	
115	5416043810	TAMPER RESIST LIMITER (W)	1	
116	5416043640	CHOKE RETURN SPRING	1	
117	5416043560	CHOKE CONTROL LEVER	1	
118	5416043660	CHOKE LEVER	1	
119	5416043610	CHOKE SHAFT COLLAR	1	
120	5416043710	CHOKE LEVER SCREW	1	
121	5416043820	PUMP COVER KIT	1	
122	5413048001	CLEANER PLATE ASS'Y	1	
123	5413507001	AIR CLEANER CASE	1	
124	5413507101	AIR CLEANER ELEMENT	2	
125	5413507200	AIR CLEANER GASKET	2	
126	0043605140	Csavar M5x14 RBC250/220/RB	1	
127	5416504302	CARBURETOR GASKET	1	
128	0043605550	SCREW	2	
129	5416504600	CABLE BRACKET	1	
130	5216008010	ADJUST SCREW	1	
131	0022706000	NUT M6	1	
132	5413507900	CARBURETOR GASKET	1	
133	5413507800	PLATE	1	
134	6625001002	CONTROL LEVER ASS'Y INC. 135-150 INC. 135-150,156,157	1	
135	6625500500	CASE COVER	1	
136	6625003001	SWITCH COMPLETE	1	
137	6625500601	THROTTLE LEVER 1	1	
138	6625500701	THROTTLE LEVER 2	1	
139	6625004000	PLATE COMPLETE	1	
140	6625500901	TORSION SPRING	1	
141	0630139901	CONTROL CABLE	1	
142	6625501001	CABLE TUBE	1	
143	6625501700	SOCKET HEAD BOLT M6X30	1	
144	0150049970	TAPPING SCREW	1	
145	0031106000	alátét RST250	2	
146	0032206000	WAVE WASHER	1	
147	0022706000	NUT M6	1	
148	0150049940	TAPPING SCREW M4X16	4	
149	0043605250	PAN HEAD SCREW M5X25	1	
150	0043105200	PAN HEAD SCREW M5X20	2	
151	0200069920	WASHER M6	3	
152	6629508600	CAUTION LABEL	1	
153	0736409430	LABEL	1	
154	0140059921	Screw M5x8	2	
155	5413506001	TANK PROTECTOR	1	
156	6625500802	HANDLE HOLDER 1	1	
157	6625005002	HANDLE HOLDER 2	1	
A01	6709026000	BAND COMPL	2	
A02	6629019000	HOSE CLAMP	1	
A03	6629020000	HOSE CLAMP	1	
A04	6989506900	FLEXIBLE PIPE	1	
A05	6709017010	PIPE 1	1	
A06	6709017020	PIPE 2	1	
A07	6629506700	END PIPE	1	
A08	5019001000	Tool new	1	


SERVICE DRAWING

MODEL NO. PB500R




SERVICE DRAWING

MODEL NO. PB500R




SERVICE DRAWING

MODEL NO. PB500R



SERVICE DRAWING

MODEL NO. PB500R



SERVICE DRAWING

MODEL NO. PB500R

